

DUMP-LOK 109

INSTALLATION INSTRUCTIONS

1. Set the parking brake and raise the bed. Use a forklift to set the DL-109 on frame rail and position so that the DL-109 makes contact with both the bed and the frame.



2. Place safety chain around cross member on frame and pull through the chain taut through the securing slot on the DL-109.



3. Slowly and carefully lower the dump bed to secure DUMP-LOK.



**DO NOT
"POWER DOWN"
THE DUMPBOX!**

BLUERIBBON
SAFETY

DUMP-LOK.COM